

Innolumis

Nicole

INSTALLATION MANUAL







INSTALLATIEHANDLEIDING
INSTRUCTIONS DE MONTAGE
MONTAGEANLEITUNG
ISTRUZIONI DI MONTAGGIO
INSTRUCCIONES DE MONTAJE









CAUTION, RISK OF
ELECTRIC SHOCK



IEC EN60598	IP66 IP67	IK08	220-240VAC 50-60Hz					
-----------------------	----------------------------	-------------	-----------------------	--	--	--	--	--





**USE CORRECTLY RATED POWERCORD, ACCORDING TO LOCAL LEGISLATION
ALWAYS USE FERRULES WHEN CONNECTING THE POWERCORD TO THE LUMINAIRE
CHECK MARKINGS ON POWERENTRY CONNECTOR WHEN CONNECTING THE POWERCORD**

**PLEASE MAKE SURE TO LUBRICATE ALL NUTS/BOLTS WITH AN APPROPRIATE GREASE OR
LUBRICATION. SUGGESTION: KROON OIL CERAMIC GREASE.**

**THE LIGHT SOURCE CONTAINED IN THIS LUMINAIRE SHALL ONLY BE REPLACED BY THE
MANUFACTURER OR HIS SERVICE AGENT OR A SIMILAR QUALIFIED PERSON.**

Innolumis Public Lighting B.V.

Ariane 4
3824 MB Amersfoort
the Netherlands
T +31 (0)33 760 04 34
F +31 (0)33 760 01 35
E info@innolumis.com

Innolumis

www.innolumis.com